





Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	56552011A	Piston assy	SN 5320303543			BT6-095-06/11
2	2	3801068R	Screw				
3	1	56560020BR	Complete muffler				
4	1	56550033R	Deflector				
5	1	3055101	Spark plug				
6	4	3801047	Screw				
7	4	3916004R	Washer				
8	2	61170014	Spacer				
9	2	093000167R	Ring				
10	1	072700045R	Piston pin				
11	2	61050046R	Piston ring	SN 5323138649			BT6-095-06/11, BT6-100-05/13
12	1	56552012B	Complete cylinder	SN 5323138649			BT6-095-06/11, BT6-100-05/13
13	1	61240047AR	Motor housing				
14	2	3050022AR	Seal ring				
15	2	3034009R	Bearing				
16	2	074000267AR	Spacer				
17	1	072700046R	Bearing				
18	1	56560001R	Crankshaft				
19	1	4098232R	Key				
20	1	56562009A	Short block	SN 5323138649			BT6-100-05/13
21	1	56550143R	Net				
22	1	56550159R	Gasket				
23	1	56560021AR	Deflector				
24	2	012000028	Screw				





Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61070019AR	Starter rope				
2	1	61200015R	Starter handle				
3	1	072700089R	Bushing				
4	1	61070036R	Spring				
5	1	61172004R	Complete pulley				
6	1	3960070AR	Screw				
7	1	094600054	Washer				
8	1	61170173R	Washer				
9	1	56560038AR	Cover				
10	3	3960091AR	Screw				
11	2	61070039R	Spring				
12	2	61070038R	Pawl				
13	1	56560034R	Clutch driver				
14	1	56550180R	Cap and spring				
16	1	56550145BR	Ignition coil				
17	1	56550134R	Flywheel				
18	2	4191069BR	Plate				
19	2	3960030	Screw				
20	1	56560057R	Cable				
21	1	56560055R	Cable				
22	1	3916004R	Washer				
23	1	006000315R	Washer				
24	1	3801007	Screw				



Fino a matr. 5322096818 /
Until sn 5322096818





Da matr. 5322096819 /
From sn 5322096819




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	56550115R	Gasket				
2	1	61240009DR	Insulator				
3	2	61200021AR	Gasket				
4	1	2318816BR	Carburetor WT-936A				
5	1	56550157R	Flange		SN 5322096818		BT6-098-03/12
6	1	56560005R	Starter lever		SN 5322096818		BT6-098-03/12
7	-	-	Not available for this product				
8	2	3801012	Screw		SN 5322096818		BT6-098-03/12
9	1	56560022R	Filter		SN 5322096818		BT6-098-03/12
10	1	56560025R	Cover		SN 5322096818		BT6-098-03/12
11	1	4098658AR	Breather valve		SN 5322096818		
12	1	4100308AR	Gasket		SN 5322096818		
13	1	4151258R	Complete cap		SN 5322096818		
14	1	2318817R	Air purge				
15	1	56570045R	Tube				
16	1	56560053R	Tube				
17	1	56560052R	Fuel hose				
18	1	4098377R	Band				
19	1	094600450R	Fuel filter				
20	1	56560079R	Deflector				
21	1	56562003R	Filter support		SN 5322096818		BT6-098-03/12
22	2	3916005R	Washer		SN 5322096818		BT6-098-03/12
23	1	56570059R	Gasket				
24	2	56570058R	Gasket	SN 5322096819			BT6-098-03/12
25	1	56570049R	Flange	SN 5322096819			BT6-098-03/12
26	1	3960121R	Screw	SN 5322096819			BT6-098-03/12
27	1	56570041R	Starter lever	SN 5322096819			BT6-098-03/12
28	1	56570047AR	Air filter support	SN 5322096819			BT6-098-03/12
29	1	320000004	Screw	SN 5322096819			BT6-098-03/12
30	1	56570042R	Shutter	SN 5322096819			BT6-098-03/12
31	1	56570043R	Cover	SN 5322096819			BT6-098-03/12
32	2	3819006R	Washer	SN 5322096819			BT6-098-03/12
33	1	56570040R	Air filter flock	SN 5322096819			BT6-098-03/12
34	1	56570050R	Air filter cover	SN 5322096819			BT6-098-03/12
35	1	61330040AR	Screw	SN 5322096819			BT6-098-03/12
36	1	56572009	Air filter kit	SN 5322096819			BT6-098-03/12
37	1	4161211R	Bush				
38	1	61070006R	Gasket	SN 5322096819			
39	1	61070079AR	Tank cap	SN 5322096819			
40	1	56570046R	Breather fuel pipe	SN 5322096819			
41	1	61070011AR	Breather valve	SN 5322096819			


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	56560056R	Cable				
2	1	2317021R	Switch				
3	1	56560051R	Throttle cable				
4	1	56560063R	Half grip				
5	1	56550156R	Button				
6	1	56550023AR	Throttle				
7	1	56560058R	Stopper				
8	1	56550026R	Lever				
9	3	3960091AR	Screw				
10	1	56560015R	AV-mount				
11	1	3801013R	Screw				
12	2	56510050R	Washer				
13	1	56560062AR	Half grip				
14	1	56560028AR	Left cover/tank			SN 5322096818	
14	1	56572008R	Right cover	SN 5322096819			
15	1	3818011AR	Washer				
16	1	56560017R	Extension				
17	1	56560003R	Cover				
18	1	56560010R	Fan				
19	1	56560027AR	Knife				
20	1	3980012	Nut				
21	1	56560023AR	Left cover				
22	1	56560046R	Spring				
23	1	56550123R	Pin				
24	1	3918010R	Washer				
25	1	3960070AR	Screw				
26	2	3801012	Screw				
27	2	3916005R	Washer				



3 **Optional**



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	56550073R	Tube				
2	1	56550127R	Tube				
3	1	56562001A	Suction kit				
4	2	3960121R	Screw				
5	1	56562006	Labels kit				
6	1	56552010R	Tool kit				
7	1	56560029R	Tube				
8	1	56550078AR	Grassbag				
9	1	56560067R	Tube				
10	1	56550076AR	Tube				



■ 13 KIT RIPARAZIONE
REPAIR KIT

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	003300197	Screw				
2	1	2318777	Cover				
3	1	094600148	Spring				
4	1	074000240	Adjust. screw				
5	1	50010141	Screw				
6	1	375100078	Shutter				
7	2	095000164	Ring				
8	1	2318211	Pin				
9	1	2318737	Shaft				
10	1	072700347	Spring				
11	1	2318779	Screw L				
12	1	2318191	Cover				
13	1	2318671	Repair kit				
14	1	003300202	Screw				
15	4	035000162	Screw				
16	1	2318778	Adjust. screw				
17	1	003300201	Spindle				