











Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	005000122	Starter handle				
2	1	006000829	Washer				
3	1	365000107	Starter rope				
4	1	365200236R	Muffler				
5	1	028200069R	Nut				
6	1	365000109	Spring				
7	1	365000104	Cover				
8	2	3801013R	Screw				
9	2	3916005R	Washer				
10	1	365000105	Starter pulley				
11	1	365000108R	Spring				
12	1	365000111	Pawl				
13	1	365000110	Spring				
14	1	365000101	Washer				
15	1	365000102	Washer				
16	1	099900197	Screw				
17	1	3819005R	Washer				
18	1	365200166	Throttle cable				
19	1	365000100AR	Starter assy				
20	1	365200277R	Flywheel				
21	1	3818011AR	Washer				
22	1	3912009	Nut				
23	1	365200057A	Gasket set				
24	1	365200122	Spacer				
25	1	094600169A	Spring				
26	1	094600097AR	Spark plug cap				
27	1	365200279R	Ignition coil				
28	2	006000024R	Screw				
29	2	3916004R	Washer				
30	1	2318480R	Carburetor				
31	2	3801024R	Screw				
32	2	365200020	Gasket				
33	1	365200019	Manifold				
34	1	3055115	Spark plug bpmr7a				
35	4	3801024R	Screw				
36	1	365200131R	Cylinder				
37	1	50110007R	Knob				
38	1	365200015	Gasket				
39	2	365000092	Screw				
40	4	3833076	Washer				
41	4	3914006R	Nut				
42	3	3023008R	Plug				
43	1	365200310B	Air filter kit				
44	1	365200225R	Air filter				
45	1	365200069DR	Crankshaft				
46	2	3833076	Washer				
47	1	365200021AR	Gasket				
48	2	365200007R	Piston ring				
49	2	007201198R	Ring				
50	1	006000012R	Piston pin				
51	1	365200211	Crankcase assy				
52	4	3801066	Screw				
53	1	365200110	Piston assy Ø48				
54	1	006000010	Bearing				
55	2	301000047R	Key				
56	2	3050015AR	Seal ring				
57	2	3034012R	Bearing				
58	2	3918005	Washer				
59	1	3819006R	Washer				
60	2	3801009	Screw				
61	2	3819009R	Washer				
62	1	365200284	Flywheel and coil kit				
63	1	365200247BR	Filter cover				
64	1	365200312R	Short block				
65	1	365200267R	Gasket				








Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	365100098A	Cap				
2	1	365100084B	Gasket				
3	1	365000043B	Filter				
4	1	365000044R	Tube				
5	1	365200328A	Tank				
6	4	3914006R	Nut				
7	1	365200159	Padding				
8	4	034000013	Nut				
9	8	004000090	Washer				
10	2	365000046	Gasket				
11	2	365200078R	Ring nut				
12	2	365000041	Fitting				
13	2	365200150A	Clamp				
14	2	365200158	Harness				
15	1	365200172	Anti-vibration kit				
16	2	3801032R	Screw				
17	3	365200149R	Rivet				
18	1	3833076	Washer				
19	4	3801027R	Screw				
20	4	50070049R	Support				
21	4	3960112	Screw				
22	4	3918005	Washer				
23	2	3801032R	Screw				
24	1	365200113	Fuel tank				
25	1	300000022R	Tank cap				
26	1	300000025	Gasket				
27	1	300000029AR	Cock				
28	1	365000049A	Suction tube				
29	1	3055098	Ring				
30	1	3049006R	O-ring				
31	1	3912011R	Nut				
32	3	365200316	Pin				



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	365000070	Nut				
2	1	365000230	Washer				
3	1	016000049	Washer				
4	1	365200280R	Guard				
5	1	365200207ER	Half volute				
6	1	365000203CR	Fan				
7	1	365200276BR	Half volute				
8	1	330000003	Band				
9	1	365100025A	Blower				
10	1	365200246AR	Engine cover				
11	1	365100062A	Double jet				
12	1	300000073	Gasket set		SN 534400868		BT6-106-12/13
13	1	365100072	Chain				
14	1	365200082	Tube				
15	1	365200093	Sleeve				
16	1	365100006	Tube				
17	1	365000008	Tube				
18	1	365200114	Dusting kit				
19	1	365000002	Tool kit				
20	1	365200289	Labels kit				
22	1	301000238	Cover		SN 534400868		BT6-106-12/13
23	1	301000237	Valve		SN 534400868		BT6-106-12/13
24	1	034000013	Nut		SN 534400868		BT6-106-12/13
25	1	300000221	Screw		SN 534400868		BT6-106-12/13
26	1	300000220	Spring		SN 534400868		BT6-106-12/13
27	1	365200046	Bushing				
28	1	3801026R	Screw		SN 534400868		BT6-106-12/13
29	1	300000195	Valve		SN 534400868		BT6-106-12/13
30	1	300000226	Clamp		SN 534400868		BT6-106-12/13
31	1	300000228	Pin		SN 534400868		BT6-106-12/13
32	1	300000227	Spring		SN 534400868		BT6-106-12/13
33	1	302000156	Jet 58		SN 534400868		BT6-106-12/13
34	1	300000222R	Needle		SN 534400868		BT6-106-12/13
35	1	300000198	Float		SN 534400868		BT6-106-12/13
36	1	300000225	Pin		SN 534400868		BT6-106-12/13
37	1	300000217	Fuel filter		SN 534400868		BT6-106-12/13
38	1	300000079	Tank		SN 534400868		BT6-106-12/13
39	2	006000315R	Washer		SN 534400868		BT6-106-12/13
40	2	3908005	Screw		SN 534400868		BT6-106-12/13
41	1	300000215	Screw		SN 534400868		BT6-106-12/13
42	1	365200045	Spark plug cap		SN 534400868		BT6-106-12/13
43	4	3960121R	Screw				
44	9	300000058R	Screw				
45	9	365200039	Nut				
46	3	3918005	Washer				
47	3	3819006R	Washer				
48	3	3801009	Screw				
49	1	365200281	Joint				



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
50	1	3024010R	Snap ring				
51	2	3035230R	Bearing				
52	3	3960067AR	Screw				
53	1	56020102	Shaft				
54	1	3049064R	O-ring				BT6-117-05/16
55	1	56020103R	Impeller				
56	1	3050055R	Seal ring				BT6-117-05/16
57	2	365200293	Tube				
58	6	3059006	Band				
59	3	3960063	Screw				
60	1	365200273AR	Booster pump kit				BT6-117-05/16
61	1	365200273AR	Booster pump kit				
62	1	365200294	Tube				
63	1	2318709	Adjust. screw		SN 534400868		BT6-085-01/10, BT6-106-12/13
64	1	300000199	Nut		SN 534400868		BT6-085-01/10, BT6-106-12/13
65	1	2318708	Pipe		SN 534400868		BT6-085-01/10, BT6-106-12/13
66	1	365200287	Fitting				
67	1	365200337A	Plate	SN 5342428285			BT6-099-12/12
68	1	2318480R	Carburetor		SN 534400868		BT6-106-12/13
69	1	300000216	Fittings	SN 5343400869			BT6-106-12/13
70	1	2318489R	Fuel filter	SN 5343400869			BT6-106-12/13
71	1	2318485R	Jet	SN 5343400869			BT6-106-12/13
72	1	2318486R	Needle	SN 5343400869			BT6-106-12/13
73	1	2318496R	Float	SN 5343400869			BT6-106-12/13
74	1	2318494R	Tank	SN 5343400869			BT6-106-12/13
75	1	2318480R	Carburetor	SN 5343400869			BT6-106-12/13





Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	365200327R	Throttle cable				BT6-085-01/10
2	1	365200189	Cable				
3	9	3960067AR	Screw				
4	1	56520068	Washer				
5	3	56520065	Flange				
6	1	61040053R	Plate				
7	1	61040051	Slide control				
8	1	56520062	Lever				
9	2	3057007	Spring				
10	1	365200169C	Half grip				
11	1	61040054R	Plate				
12	1	56520081	Spring				
13	1	365200170B	Half grip				
14	1	3960091AR	Screw				
15	1	3960061AR	Screw				
16	1	56520064	Limiter switch				
17	1	56520061R	Throttle				
18	1	365200038	Tube				
19	1	365200174BR	Handle				
20	1	365000023	Tube				
21	1	365100015	Tube				
22	1	365100086R	Cock				
23	1	56020076BR	Cock				
24	1	365000012	Cap				
25	1	365200167R	Spacer				
26	1	365200173A	Complete hose				
27	1	008200281R	O-ring				
28	1	365100018	Cock				
29	1	028200069R	Nut				
30	1	3801004	Screw				
31	1	365100001	Diffuser				
32	1	011500131	Screw				
33	1	365100071	Spacer				
34	1	365200104	Gasket				
35	1	365200092	Sleeve				
36	1	365200115R	Tube				
37	1	365200160	Elbow and clamp				
38	1	3059014	Band				
39	1	365100010	Shield				
40	1	365200286R	Cable				